



We have tried it and it is very workable, has a good pot life while you're trowelling and doesn't need a primer." – Client Testimonial.
pinfix nano-cement for concrete fills super-fine pinholes, small air voids, pop-outs, cracks and other gaps in the concrete surface to create a monolithic surface ideal for all polished concrete applications.

pinfix is available in white and natural grey. All CC colours are available upon request. Ideal for all concrete surfaces including polished concrete floors and benchtops. Designed by CC for a superior finish.



advantages

- Natural Portland cement based, meant to bond with concrete
- Fills the finest of pin holes
- Easy to apply by hand or machine
- Good pot life
- Doesn't need a primer
- Ideal for grouting all polished concrete surfaces
- Excellent for natural crack repair
- Can add Extra Fine Sand for patch repair

crack repair

- Identify and solve the cause of the cracking
- Do a small test area first
- Thoroughly clean the crack and adjacent area through careful brushing, vacuuming, blowing and wet washing. Keep the crack edges as vertical and sharp as possible. Do not Vee.
- Hand buff with a Twister white, wet 100 grit wet/dry polishing pad or 100 grit rubbing block.
- Mix CC Pinfix, 100ml water to 300g Pinfix
- Spread along the crack with a spatula, push/rub in with your finger
- Leave for 24hrs (4hrs minimum)
- Remove with wet/dry 100 diamond polishing pad
- Bring surface finish to equate to surrounding area e.g., 3000 for polished

No concrete priming is required.

ventura
real concrete overlay

pacifica
terrazzo benchtops

polished concrete pinfix

- At grouting stage, normally after 100 resins, thoroughly clean the floor
- Mix CC Pinfix, 100ml water to 300g Pinfix
- By hand, use grout spreader or dry machine with grouting plates
- Do manageable sections, say 3-4m at a time
- Let cure for 24hrs (4hrs minimum)
- Remove with 100 resins (rubbing block or machine) wet or dry
- Finish floor to the desired sheen

No concrete priming is required.

concrete patch

- Thoroughly clean & prepared the area
- Mix CC Pinfix with up to 50% Extra Fine Sand
- Shape
- Let cure for 24hrs (4hrs minimum)
- Finish to desired Sheen

collaborate:

w www.concrete-collaborative.com.au
e sales@concrete-collaborative.com.au
p 1800 OVERLAY (1800 683 752)

